

Carron Phoenix Argenta Tap Replacing Cartridges & O Rings

Replacing the cartridge

To replace the cartridge, you will need to remove the hose. To do this, unscrew the hose from underneath the tap and pull through from the end of the spout.

Before replacing the cartridge you will need to turn the water off. You will then need to unscrew the lever (1) by unscrewing it anticlockwise. You can then remove the handle retaining screw (2) by using a 2.5mm allen key. Once you've removed the handle (3), you can then unscrew the cartridge cover (4) by unscrewing it anticlockwise. You will then be able to use an adjustable spanner to remove the cartridge locking ring (5). You can then remove the cartridge (6) and replace with the new part.

