

Carron Phoenix Barra Tap

Replacing Cartridges & O Rings

Replacing the Cartridge

Before replacing the cartridge, you will need to turn the water off. You will first need to unscrew the handle indicator (1) by unscrewing it anticlockwise. You can then use a crosshead screwdriver to remove the handle retaining screw (2). You will then be able to remove the handle (3). You can then unscrew the valve cover (4) by unscrewing it anticlockwise. You can then use an adjustable spanner to unscrew the existing valve (5) and fit the replacement parts.

Replacing the O-Rings

You will first need to unscrew the spout collar (6) by using it anticlockwise and then lift the spout (7) out. You can then replace the o rings (8) at the base with the replacement parts.

