

Carron Phoenix Integral Tap

Replacing Cartridges & O-Rings

Replacing the Cartridge

Before replacing the cartridge, you will need to turn the water off. You'll first need to remove the handle indicator (1) by prising it off. You can then remove the handle retaining screw (2) by using a crossheaded screwdriver. You can then remove the handle (3) and unscrew the valve (4) by using an adjustable spanner. You can then fit the replacement parts.

