

Carron Phoenix Victoria Tap

Replacing Cartridges & O-Rings

Replacing the Cartridge

Before replacing the cartridge, you will need to turn the water off. You will need to remove the handle indicator (1) by unscrewing it anticlockwise. Once this is removed, you'll be able to remove the handle retaining screw (2) with a crosshead screwdriver. This will then allow you to remove the handle (3). You can then unscrew the valve cover (4) by unscrewing it anticlockwise. You'll then be able to unscrew the valve (5) by using an adjustable spanner. You can then fit the replacement parts.

Replacing the O Rings

To replace the o rings, you will first need to unscrew the spout collar (6) by unscrewing it anticlockwise. You can then lift the spout (7) up and replace the o rings (8) at the base with the replacement parts.

